


Title: Input Device to Continuously Detect Biometrics
Inventors: Curtis Ikehara & Martha Crosby
Contact: Curtis Ikehara (808) 488-8911

1 / 9


FIG 1



Title: Input Device to Continuously Detect Biometrics
Inventors: Curtis Ikehara & Martha Crosby
Contact: Curtis Ikehara (808) 488-8911

2 / 9

FIG 2




Title: Input Device to Continuously Detect Biometrics

Inventors: Curtis Ikehara & Martha Crosby

Contact: Curtis Ikehara (808) 488-8911

3 / 9

FIG 3



Title: Input Device to Continuously Detect Biometrics

Inventors: Curtis Ikehara & Martha Crosby

Contact: Curtis Ikehara (808) 488-8911

4 / 9

FIG 4





FIG 5




Title: Input Device to Continuously Detect Biometrics

Inventors: Curtis Ikehara & Martha Crosby

Contact: Curtis Ikehara (808) 488-8911

6 / 9

FIG 6




Title: Input Device to Continuously Detect Biometrics

Inventors: Curtis Ikebara & Martha Crosby

Contact: Curtis Ikebara (808) 488-8911

7 / 9


FIG 7



Title: Input Device to Continuously Detect Biometrics
Inventors: Curtis Ikehara & Martha Crosby
Contact: Curtis Ikehara (808) 488-8911

8 / 9

FIG 8



9 / 9

FIG 9

